




Toshiba Satellite 1415-S105 Upper Case Replacement

Prerequisite Only

Written By: Kiril Lange



INTRODUCTION


Prerequisite Only



TOOLS:



- [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Upper Case




- Disconnect both speaker connectors located near the center of the laptop.

Step 2



- Unscrew all visible screws on the heat sink shield.

Step 3



- Disconnect the monitor connector.

Step 4



- Starting from the front right corner pry apart the black bottom from the gray top.

Step 5



- Set aside the top half.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-16 06:02:00 AM.